

Proxi-Fit™ Instructions

(For Marking Interproximal Contacts)




1. Pick up one strip of test ribbons with sterile forceps or cotton pliers. Cut off desired number of test ribbons (usually three) to create an individual packet.




2. Hold printed paper base of ribbon packet with the left hand. With index finger of right hand, bend ribbon end of packet tightly over left index finger.



3. Bend clear sheet and hold against printed paper base between thumb and index finger of right hand.




4. Pinch clear protective and paper backing sheets with thumbs and index fingers of both hands at base of ribbons to crease protective sheets and cause ribbons to stand upright.



5. When creased, paper backing sheet and printed paper base make a convenient stand for ribbon packet.



6. Grasp Forcep handle with all four fingers of right hand, bring both wrists together to support each other. Depress button with right thumb to open jaws of forceps.



7. With Forceps jaws open, bring jaws over free end of most lateral test ribbon.




8. Slowly release thumb button to completely grip test ribbon tightly.



9. With a small quick jerk, pull ribbon toward you to release ribbon from adhesive in ribbon packet.



 3060: If used more than one time, patient cross-contamination may occur.